

Commissioning and reset

6. Initial commissioning

CAUTION

The ID21 system must first be fully installed (see chapters 4 and 5) and all components must be connected before you can carry out the initial commissioning.



It is not possible to connect a second control unit or additional lifting columns later.

6.1 Reset during commissioning

CAUTION

Danger of crushing injury!

No system-based safety mechanism is active during the reset process.

- 1 Connect the power cable to the control unit's power connection.
- 2 Insert the mains power plug into a power outlet.
- 3 Press and hold the  button (adjusting downward) until the tabletop moves all the way down.
- 4 Press the  button for at least five seconds longer.
- 5 The reset is now finished. You can now press the corresponding button to raise or lower the lifting columns.